




Pentax pumps can be used with either the traditional Pressure Tank or a Control pump, also called *Smarthead*.

Smarthead option:

The Smarthead is a compact, non-adjustable electronic device that automatically controls the operation of the pump. It replaces a pressure tank, pressure switch and float switch. With a smarthead, if your water tank runs dry, the pump will shut off immediately. The Smarthead includes the following features:

- Switch for manual pump starter
- Special non return valve which avoids surges
- Security system to avoid the pump running with no water
- Pressure guage



CAM 75 w/Smarthead

Pressure Tank option:

A pressure tank works like a reservoir, storing water under pressure until needed. When a tap is opened the pump will run to replace the used water. Our 18 Litre pressure tank comes with a fixed bladder which provides an air cushion that produces water pressure. This avoids your pump from turning on every time a glass of water is drawn. Pentax pressure tanks are available in sizes ranging from 18 litres to 500 litres.

Caution: Always use a float switch with a pressure tank to prevent your pump from running dry.



CAM 50 w/18L p/tank

Recommended Packages

Model #	HP	Pressure Tank or Smarthead	Max. Output (GPM)	Max. Head (FT)
CAM 50	1/2	18 Litre	10	130
CAM 75	3/4	50 Litre	12	157
CAM 100	1	100 Litre	15	170

Accessories

Protect your pump from the elements with a Pentax Pump House. Suitable for pumps with smartheads only.



Guarantee

All Pentax Water Pumps and Pressure Tanks are guaranteed for a period of one (1) year. The Electric Motor and Capacitor are not guaranteed as factors such as voltage fluctuations and improper installation may affect the performance of the motor.

Distributed by:



Lot C, Don Miguel Ext. Rd., San Juan, Trinidad, W.I.
 Tel: 868-674-TANK(8265) · Fax: 868-674-8339
 e-mail: info@rotoplastics.co.tt
 www.rotoplastics.co.tt